



DS-RX1HS™

- Ideal for stationary and mobile photo booth operations.
- Low cost media combined with large print capacity!
- Inexpensive hardware cost.
- Glossy and matte photo finishes.



“These pictures last on fridges, mantle pieces, and bedroom walls for decades — and that’s the best advertising I could ask for, I’m sure of it.”

-Sarah Heise, Voodoo Doughnuts

Photo Booth Ready

The durable design allows the DS-RX1HS to fit easily into photo booths, an existing kiosk cabinet, or smaller retail space.

High Volume

With a capacity of 700 4x6" prints, the DS-RX1HS lets you run the printer in long cycles before the need to ever change media.

Low Price Media

The DS-RX1HS offers a low-cost approach with its economic photo consumables, while ensuring a standard printing quality. It delivers prints with matte or glossy finishes, at resolution of 300x300 to 300x600 dpi.

Our **New Status App** for Windows provides great benefits while you're shooting an event!

**Media Type Loaded • Prints Remaining
Total Print Count • Firmware Version
Color Control Data**

**DNP Printers are supported by a variety of
3rd party photo printing and photo booth
applications!**

**Contact an authorized DNP reseller to see
how the DS-RX1HS can boost your business!**

Specifications

| | |
|----------------------|--|
| Print Method | Dye-sublimation thermal transfer |
| Print Mode | High-speed mode & High-quality mode |
| Resolution | 300x300 dpi, 300x600 dpi |
| Print Number & | 4x6" 700 sheets 12.4 sec. |
| Print Speed (glossy) | 6x8" 350 sheets 22 sec. |
| Finishing Options | Glossy, Matte |
| Ribbon Finish | YMC + overcoat |
| Interface | USB 2.0 |
| Driver Software | Windows 10, 8, 7 - Mac OS-X 10.8 and up |
| External Dimensions | 12.6" W x 13.8" D x 11" H |
| Weight | Approx. 30 lbs |
| Power Supply | AC100V, 240V 50/60Hz |
| Power Consumption | 100V / 2.9A 240V / 1.2A |
| Accessories | Power cable, USB cable, driver CD, user guide, printhead cushion, quick reference card |
| Media | DS-RX1HS 4x6, 6x8 |

DS-RX1HS Print Sizes

Don't just think 2x6 is your only option. Expand your offerings with the multiple formats and media types the DS-RX1HS supports.



2x6"



4x6"



4x6", 2"
Center Perf



4x6", 2"
Single Perf



5x7"



6x6"



6x8"



6x8", 2"
Triple Strip

© 2020 DNP Imagingcomm America Corp. All rights reserved.
Reproduction in whole or part without written permission is prohibited.
Specifications subject to change without notice.